


Punte cilindriche per muro, serie lunga 400-600mm, Qualità Standard

Carbide tipped masonry drills, 400-600mm. length / Forets à béton au carbure de tungstène, série longue 400-600mm.
Brocas para hormigón, serie larga 400-600mm. / Steinbohrer, 400-600 mm Ausführung.


DIN 8039 - ISO 5468

Art. 03011 L=400 mm



Ø mm	Inch	d	l	L	pcs 	cod.	€ cad/each
6	15/64	5	240	400	5	030110600	
8	5/16	7	240	400	5	030110800	
9	11/32	8	240	400	5	030110900	
10	3/8	9	240	400	5	030111000	
11	7/16	10	240	400	5	030111100	
12	15/32	10	240	400	5	030111200	
13	1/2	10	240	400	5	030111300	
14	9/16	10	240	400	5	030111400	
15	19/32	10	240	400	5	030111500	
16	5/8	10	240	400	5	030111600	
18	23/32	10	240	400	5	030111800	
20	25/32	13	240	400	5	030112000	
22	7/8	13	240	400	1	030112200	
24	15/16	13	250	400	1	030112400	
25	1"	13	250	400	1	030112500	
26	1" 1/32	13	250	400	1	030112600	
28	1" 1/8	13	250	400	1	030112800	
30	1" 3/16	13	250	400	1	030113000	
32	1" 1/4	13	250	400	1	030113200	

Art. 03015 L=600 mm

Ø mm	Inch	d	l	L	pcs 	cod.	€ cad/each
6	15/64	5	370	600	5	030150600	
8	5/16	7	370	600	5	030150800	
9	11/32	8	370	600	5	030150900	
10	3/8	9	370	600	5	030151000	
11	7/16	10	370	600	5	030151100	
12	15/32	10	370	600	5	030151200	
13	1/2	10	370	600	5	030151300	
14	9/16	10	370	600	5	030151400	
15	19/32	10	370	600	5	030151500	
16	5/8	10	370	600	5	030151600	
18	23/32	10	370	600	5	030151800	
20	25/32	13	370	600	5	030152000	
22	7/8	13	370	600	1	030152200	
24	15/16	13	370	600	1	030152400	
25	1"	13	370	600	1	030152500	
26	1" 1/32	13	370	600	1	030152600	
28	1" 1/8	13	370	600	1	030152800	
30	1" 3/16	13	370	600	1	030153000	
32	1" 1/4	13	370	600	1	030153200	

Applicazioni / Applications



Si consiglia di eseguire un preforo di 100÷150 mm, dello stesso diametro.
Use same size pilot drill for 100÷150 mm. depth.