

Linergy busbars, supplied by a 1600 A Masterpact NW16 drawout circuit breaker via transfer busbars.

Incoming device:

Compact circuit breaker

Masterpact NT 06/16 circuit breaker

Cubicle types:

■ Prisma P, depth = 400 mm

■ Prisma PH, depth = 500 mm.

Busbar layout



Linergy busbars

description

cat. No.

Linergy busbar supports for Prisma

P, D = 400

07371

PH, D = 500

07490

Linergy bottom support for Prisma

P, D = 400

07373

PH, D = 500

07492

Transfer busbar support

The bars are secured to 2 cross-members by 2 insulated supports

description

cat. No.

set of 2 side cross-members

07424

insulated support

2 x **07413**

Terminal extension bar support

The bars are secured to a rear cross-member by an insulated support.

description

cat. No.

1 rear cross-member

07427

1 insulated support

07413

Incoming device:


Masterpact NW 08/16 circuit breaker (1600 A)

Cubicle type:

■ Prisma P, depth = 600 mm

■ Prisma PH, depth = 700 mm.

Busbar layout



Linergy busbar

description

cat. No.

Linergy busbar supports for Prisma

P, D = 600 (1)

07371

PH, D = 700

07491

Linergy bottom support for Prisma

P, D = 600

07374

PH, D = 700

07493

(1) Linergy busbar supports should be mounted on a functional upright installed in the duct.

description

cat. No.

Set of 2 functional uprights

09625

Transfer busbar support

The bars are secured to 2 cross-members by 2 insulated supports.

description

cat. No.

set of 2 side cross-members

07424

insulated support

2 x **07413**

Terminal extension bar support

The bars are secured to a rear cross-member by an insulated support.

description

cat. No.

1 rear cross-member

07427

1 insulated support

07413